



Manual
 Gebruiksaanwijzing
 Gebrauchsanweisung
 Mode d'emploi
 Manual
 Bruksanvisning
 Brugsvejledning
 Käyttöopas
 Uživatelská příručka
 Používateľská príručka
 Εγχειρίδιο χρήσης
 مَدْخَتْ سَمَال لِي د

XR105



#MOREENERGY

XTREME SERIES - Power your adventures

①



- 10.000mAh Li-Polymer
- 165x100x21mm
- 420g
- Output:** 1x USB-C 5V/3A, 9V,2,22A,12V/1,67A (PD20W max)
2x USB-A 5V/3A, 9V/2A, 12V/1,5A (18W max)
- Input:** USB-C 5V/3A, 9V/2,22A, 12V/1,67A (PD20W max)
- Total output:** 5V/3A
- USB to USB-C cable, carabiner and manual




②



③



④



⑤



⑥



Best illumination angle

Best time of the day
 09:00-15:00

Do not leave out in the rain

The solar panel doesn't work behind a window

IMPORTANT When charging for the first time we recommend that you charge the Solar Charger by USB with the included cable.

Also, when the internal battery of the Solar Charger is completely empty, you may have to charge it by USB power for a few minutes. Sometimes the charger needs a small energy boost before being able to generate solar power into energy.



⑦



LED POWER INDICATORS
POWER BUTTON

CHARGING INDICATION:
Press button 1x

LIGHT ON LIGHT OFF



XTREME SERIES - Power your adventures

